




Basic Training for Titan

Trainer: Ruo Yi (Technical Support Engineer)

05.07.2022




Agenda

- Brief Introduction of Titan
- Installation
- Commissioning
- Q&A






Brief Introduction



Overview



High efficiency >95%

Dual connector (each could be up to 180kW max. output)

Automatic load balance

Simultaneous charging

CCS2*2 (200A 1000V)

Wide output voltage 200-1000Vdc

Modular design, easy upgrade.

Overview




Specifications



Titan 180 Premium		
Power Input	Input Rating	400Vac±10%, 3-Phase, 50/60 Hz, L1+L2+L3+N+PE
	Power Factor	0.99 at nominal output power
	Current THD	≤5% at nominal output power
	Efficiency Rectifier	≥95% at nominal output power
Power Output	Output Interface	Configuration1: 2 x CCS2 Configuration2: CCS2 + CHAdeMO
	Output Power	CCS2: 180kW max., CHAdeMO: 62.5kW max.
	Output Voltage	CCS2: 200-1000Vdc, CHAdeMO: 200-500Vdc
	Output Current	CCS2: 200A max., CHAdeMO: 125A max.
User Interface & Control	Display	10.4" LCD Touch Panel
	Support Language	Simplified chinese, English, Other languages available upon request
	Push Buttons	Emergency stop button
	RFID Reader	ISO/IEC 14443 A/B Mifare RFID reader
Communication	Network Interface	4G, Wi-Fi, Ethernet
	Protocol	OCPP1.6J
Environmental	Operating Temperature	-30°C - 50°C
	Storage Temperature	-40°C - 70°C
	Humidity	5%-95% no condensation
	Altitude	≤2000m
Mechanical	Ingress Protection	IP55
	Enclosure Protection	IK10
	Cooling	Forced air
	Charging Cable Length	5m
	Dimension (WxHxD)	800*2050*750mm (depth without connector holder)
	Weight	approx. 395kg (excluding power modules)
	Installation	Ground-mounted
Regulation	Certificate	CE, TR25



Installation



Installation Requirements



1.Site conditions


- Altitude \leq 2000m
- Historical maximum ponding water depth \leq 200mm
- Keep distance from the gas station and other highly flammable and explosive facilities

Installation Requirements





2.Requirements for grid capacity

- If the charging pile operates at full power, the grid capacity shall meet 200KVA, the rated current parameter shall be 280A.
- Recommended parameters of superior circuit breaker UE = 400VAC, $I_n = 400A$, thermal magnetic type, $I_{cu} = I_{cs} = 40KA$, 4Poles



3. Maintenance distance





Installation Requirements



4.Dimension of concrete base

The size of the cement base is 900mm*850mm*600mm mm, the depth of burial of the base is 400 mm and the height of the ground is 200 mm.




Installation Requirements



5. Power cable specification

For full output power (180kW) , the charger's power cable to be laid is not less than $3 * 150\text{mm}^2 + 2 * 70\text{mm}^2$, the core material is copper, and the length above the base is about 1m.



1. Unpacking inspection

Name	Photo description (before unpacking)	Configuration	Attached file	Accessories list
180kW DC charger		1	Certificate of approval Delivery inspection report The user manual	Key*6 Start&Stop card*2
Module		6		Screws*4



Check the following items:

- packing list number and equipment quantity.
- equipment nameplate information.
- whether the documents are complete.
- whether spare parts and accessories are complete
- Factory inspection report and certificate.
- whether the appearance of equipment is in good condition

Installation Process

2. Fill out unpacking record form

- The installer open crate in the presence of customers and fill in the unpacking record sheet.
- After unpacking inspection, invite owner's representative to confirm and sign on the unpacking record sheet.
- In case of any problem found during the unpacking inspection, besides making record, notify the supplier.

		Unpacking record list	
Name	Quantity		
Charger (DH-DC1800SG40-B)	1		
Certificate	1		
IC Card	1		
Factory Inspection Report	2		
Instruction Manual	1		
Key	1		
Power Module (SC75040-E)	2		
	6		
Installation Company			
Client Company			

3. Drill holes in concrete base

- Positioning and punching with mould. The depth of drilling shall be not less than 100 mm.
- Tap the M10*120 expansion bolt into the positioning hole.



Installation Process




4.Lifting preparation

First remove the front and rear sealing plates of the base by screwdriver.



4.Lifting & Fixing

- Lift the charger by using a crane (more than 3 tons) and two 6m slings (each 1.5T) through the sealing hole
- Align the fixing hole at the bottom of the charge with the fixing bolt on the foundation, lower it slowly.
- Fix the nut with a wrench .
- Install the base sealing plate after the charger is fixed.



5. Input cable handling

a) Remove the outermost cable insulation layer and pass each phase line through the cable gland




Installation Process



5. Input cable handling

b) Use heat shrinkable tubing that meets the withstand voltage level to strengthen the insulation of the cable.



Installation Process



5. Input cable handling

c) Crimping copper nose.(more than 5 times).



5. Input cable handling

d) heat the shrinkable tubing and deal with the exposed part of the copper nose.





6. Grounding/Insulation testing

- Check the civil grounding resistance, must be $\leq 4\Omega$.
- Check the civil insulation resistance, must be $\geq 10M\Omega$.



7. Electrical wiring

- Connect the power cable to the terminal.
- Make sure the screws of the wiring are fastened. When installing and connecting, avoid the damage of the cable insulation.
- Add label to cables



Installation Process



8. Insert power modules

Insert 6 power modules and fix each module with 4 screws



Demo video

Preparación de herramientas de instalación

Inspection after installation



1. Check before power-on

(1) Short circuit: check the power supply line in the low voltage distribution cabinet, there should no short circuit between the three-phase wire, neutral wire and ground wire.

(2) Power supply voltage : Check whether the power supply voltage on upper end of MCCB in the low-voltage distribution cabinet is normal, ensure there are no lack-phase, over voltage, under voltage, phase sequence abnormality and other abnormalities.

Inspection after installation



2. Check after power-on

- (1) The line voltage at the outlet terminal of the distribution box is about 400V ($\pm 5\%$), phase voltage is 230V($\pm 5\%$)
- (2) The line voltage of charger inlet terminal is measured to be about 400V ($\pm 5\%$), phase voltage is 230V($\pm 5\%$)



Fill in the installation information




Unpacking record						
Name of distribution store					Date of unpacking	
	No.	Name of commodity	Quantity	Inspection status	Note	
Box1	1	DC	1			
	2	Certificate of approval	1			
	3	IC card	2			
	4	Delivery inspection report	1			
	5	The user manual	1			
	6	Key	6			
Box 2						
	1	Module	6			
	2	Screw	24			
	3					
Unpacking result						
Signature block	Installation unit		owner's unit			



Star Charge®

Commissioning



Commissioning Tools

Item	Tools	Usage	Example
1	Laptop	Configure the settings, And read the log	
2	Ethernet cable	Parameter Configuration	
3	J - LINK tool	Programming	
4	5/6 pin adaptor	Programming	
5	TF Card and reader	Programming	
6	Screwdriver set	Assemble and disassemble the screws	


Commissioning Tools

Item	Tools	Usage	Example
7	Wrench set	Standby	
8	Electrical multimeter	Electric measurement	
9	Megohmmeter	Test the insulation	
10	Safety Sign	Warn potential danger on site	
11	Electrician protective gloves	Safety protection	
12	Electrician protective Shoes		

Commissioning Flowchart



Commissioning Flow Chart for DC EVSE



Installation Recheck Basic Check




1. Pedestal: whether fixed and sealed well.
2. Inlet cable: whether the specification of all the cable used meet the requirement of EVSE, whether there is any break, damage, or scratch, whether the electrical connection is correct and complete, whether the connection is stable and solid, whether the grounding is reliable.
3. Grounding/Insulation resistance: The external grounding resistance must be $\leq 4\Omega$, the internal grounding resistance must be $\leq 0.1\Omega$. The inlet cable insulation resistance must be $\geq 10M\Omega$. The outlet cable insulation resistance must be $\geq 1M\Omega$.
4. Outside appearance of cabinet: The surface of cabinet is intact without any dirt, and the charging cable is not broken or damaged. All doors of cabinet can be opened, closed and locked. The cabinet is not tilting, shaking or reverse assembling.
5. Nameplate and sign: Check whether nameplate and other signs are printed correct and complete, whether the safety sign is posted in correct place.
6. Documents with EVSE: Check with the customer whether the configuration information of the EVSE on site complies with the contract requirements and whether the accessories are complete.

Check before Power on Internal Wiring

1. Short circuit: Check the inlet cable to the EVSE. Check whether there's any short circuit between 3-phase live wire, neutral wire and grounding wire and whether the phase sequence is correct.
2. Fasten screw: Check whether the fastening torque of each line connection, connector, terminal with screw and brass plate can meet the requirement, and whether there's any looseness, poor connection and etc.
3. Input Voltage : check whether the input voltage of the main breaker inside of the EVSE is correct, and make sure there's no fault such as phase loss, overvoltage, undervoltage and wrong phase sequence.

Check after Power on Basic Check

1. Voltage check after power on: Check whether the output voltage of the mainbreaker inside of the EVSE is correct, and make sure there's no fault such phase loss, overvoltage, undervoltage and wrong phase sequence.
2. Touch screen: Check whether the touch screen displays normal, has obvious dead pixel, displays words clearly, is operated well and clear UI.
3. LED indicator light: Check whether the LED indicator light on the EVSE works as the design requirement.
4. Switching power supply: Switch power supply can provide stable voltage power. Use electrical multimeter to check whether the output voltage of switching power supply inside of the EVSE meets the requirement.




Parameter Configuration

Establish 4G Connection

To connect to the network, insert the SIM (mini SIM) according to the location of 4G communication module.

Before inserting the SIM, the charger needs to be switched off.





Parameter Configuration

Establish the Ethernet Connection



Connect the main board to the laptop by an Ethernet cable, and set the IP address as shown in the following picture (192.168.88.xxx, xxx can be any number but 206)



Parameter Configuration



Log into configuration website of charger



Open the browser and enter IP address 192.168.88.206,
log in with

username **xxcd** and password **28912891**

Or username **wbdh** and password **26835941**




Parameter Configuration

Change the Language




Change the language according the picture below.



Parameter Configuration

Software Setting: Network Priority:

1. Find “Network priority selection”
2. Set the priority, Ethernet>4G>WIFI for default



The screenshot displays the Star Charge web interface for software settings. The left sidebar contains navigation options: Home, Hardware Setting, Software Setting (highlighted), Charging Status, Power Module Status, Sensor Status, Intelligence operations, and Upload and download. The main content area is titled "Software Setting" and includes a breadcrumb trail: Home / Setting / Software Setting. A section titled "New version of network Settings" contains a "Network priority selection" box, which is highlighted with a red rectangle. This box features three dropdown menus: "Priority No.1" set to "Eth0", "Priority No.2" set to "4G", and "Priority No.3" set to "Wlan". Below this, the "4G configuration" section includes a checked "Enable modification" checkbox, and fields for "APN", "User", "Psw", "Pin", and "EncryptType" (set to "A"). The "Ethernet configuration" section includes a "Dhcp enable" checkbox and fields for "ip" (192.168.1.136), "netmask" (255.255.255.0), and "gateway" (192.168.1.1).

Parameter Configuration

Software Setting: 4G



1. Find "4G"
2. Click "Enable modification"
3. Set APN, User, Psw, Pin according to actual usage
4. Click "Save"
5. Click "Test"
6. Click "Reload configuration"

A screenshot of the Star Charge web interface showing the "Network" configuration page. The "4G" section is highlighted with a red box. The "4G" section includes a checkbox for "Enable Configuration" which is checked, and four input fields for "APN", "User", "Psw", and "Pin". Below these are a dropdown for "EncryptType" set to "A". The "Ethernet" section has a checked "Dhcp Enable" checkbox. The "DNS configuration" section has an unchecked "Dns Enable" checkbox and two empty input fields for "DNS1" and "DNS2". The "WiFi" section has a "Mode Selection" dropdown set to "STA", and input fields for "SSID", "Psw", "Channel" (set to "0"), and "Encryption" (set to "open"). At the bottom, there are buttons for "Test", "Save", "Refresh", "Reload", and "Reset Factory Configuration". A checkbox for "Display Advanced Configuration Page" is also present.

Star Charge

Language User Set

Home

Software Configuration

CP Configuration

CP Status

Power Unit Configuration

Power Unit Status

SmartOPS

Upload And Download

Network

Network Priority

Priority No.1: Eth0
Priority No.2: 4G
Priority No.3: Wan

4G

Enable Configuration

APN: User: Psw: Pin:

EncryptType: A

Ethernet

Dhcp Enable

DNS configuration

Dns Enable

DNS1: DNS2:

WiFi

Mode Selection: STA

SSID: Psw: Channel: 0 Encryption: open

Dhcp enable

Advanced Configuration Page

Display Advanced Configuration Page


Test Save Refresh

Reload Reset Factory Configuration

Parameter Configuration-Software Setting

Ethernet:

1. Connect Ethernet cable
2. Find “Ethernet configuration”
3. Click “Dhcp enable”
4. Click “Save”
5. Click “Test”
6. Click “Reload configuration”



The screenshot displays the Star Charge software configuration interface. The left sidebar contains navigation options: Home, Software Configuration, CP Configuration, CP Status, Power Unit Configuration, Power Unit Status, SmartOPS, and Upload And Download. The main content area is titled 'Network' and includes several configuration sections:

- Network Priority:** Three dropdown menus for Priority No.1 (Eth0), Priority No.2 (4G), and Priority No.3 (Wlan).
- 4G:** A section with a checked 'Enable Configuration' checkbox, and input fields for APN, User, Pw, and Pin. An 'EncryptType' dropdown is set to 'A'.
- Ethernet:** A section with a checked 'Dhcp Enable' checkbox, highlighted by a red box.
- DNS configuration:** A section with a checked 'Dns Enable' checkbox and input fields for DNS1 and DNS2.
- WiFi:** A section with a 'Mode Selection' dropdown set to 'STA', input fields for SSID and Pw, a 'Channel' dropdown set to '0', and an 'Encryption' dropdown set to 'open'. A checked 'Dhcp enable' checkbox is also present.
- Advanced Configuration Page:** A section with a checked 'Display Advanced Configuration Page' checkbox.

At the bottom of the interface, there are buttons for 'Test', 'Save', 'Refresh', 'Reload', and 'Reset Factory Configuration'.

Parameter Configuration-Software Setting

Software Setting: WIFI



1. Find "WiFi" .
2. "Mode selection" choose "STA"
3. Fill in "SSID" (WIFI ID) "Psw" (WIFI password) "Encryption" (EncryMode, generally choose wpa2)
4. Click "Dhcpc enable"
5. Click "Save"
6. Click "Test"
7. Click "Reload configuration"
8. Finish setting, wait for 1 minute to check whether the WIFI connection works

The screenshot displays the Star Charge web interface. On the left is a dark sidebar with navigation options: Hardware Setting, Software Setting (highlighted), Charging Status, Power Module Status, Sensor Status, Intelligence operations, and Upload and download. The main content area has a top header with the Star Charge logo, "Language" dropdown, and "User Set" dropdown. Below the header, there are two sections. The first section, titled "Wifi configuration", is enclosed in a red rectangular box. It contains a checkbox for "Enable modification" (checked), a "Mode selection" dropdown menu set to "STA", input fields for "SSID" and "Psw", a "Channel" dropdown menu set to "0", and an "Encryption" dropdown menu set to "open". There is also a checkbox for "Dhcpc enable" (checked) and "Submit" and "Refresh" buttons. The second section, titled "OCPP Part", is partially visible below and includes input fields for "URL", "Path", "Port", and "SSL_ON".

Parameter Configuration-Software Setting



OCPP:

Take `http://36.153.57.202:3400/steve/websocket/CentralSystemService` as an example. The information need to be filled in is shown as below:

1. Find "OCPP"
2. "URL" : Enter IP address or domin name of the backend;
3. "Path" : Enter the path after IP in "Path"
4. "Port" : Enter Port number of backend
5. "SSL_O" : The value is 1 when the backend uses TLS for access, otherwise the value is 0.
6. "Authorization key" : If the backend doesn't use Basic authorization, just leave it blank. (no need to fill in most cases)
7. Click the "Submit" in OCPP Part to confirm delivering the setting information to the backend.
8. "Certificate Import" : Load in the CA certificate offered by customer when using TLS; otherwise, leave it blank.
9. Click "Submit" to deliver certificate if loading in the certificate.

Parameter Configuration-Software Setting

 Star Charge®

Language ▾

User Set ▾

Home

Software Configuration

CP Configuration

CP Status

Power Unit Configuration

Power Unit Status

SmartOPS

Upload And Download

OCPP

CP Backend

URL

Path

Port

SSL_ON

Authorization key

Certificate import

Additional Function

Authentication

Interaction With Backend For All

QR-Code Process

Private Data

Time Zone And DST Setting

Time Zone

DST Enable

Parameter Configuration-Software Setting



Card type:

1. "Card Not Authentication" : Local start-stop card, the EVSE can work by swiping the card without connecting to the backend.
2. "Card Authentication" : Authentication card, the UID of RFID card must be entered into backend before using, and EVSE must connect to the backend
3. "Local PNC" : plug in and charge

Click "Submit" after the configuration.

A screenshot of the Star Charge software configuration interface. The interface has a dark sidebar on the left with navigation links: Home, Software Configuration (highlighted), CP Configuration, CP Status, Power Unit Configuration, Power Unit Status, SmartOPS, and Upload And Download. The main content area is titled "Additional Function" and contains several sections: "Authentication" with a dropdown menu (highlighted with a red box) showing "Card Not Authentication", "Card Authentication", and "Local PNC"; "Interaction With Backend For All" with a dropdown set to "No"; "Private Data" with a dropdown set to "No"; "Time Zone And DST Setting" with fields for Time Zone (UTC), DST Enable (Disable), Beginning month, Beginning week, Beginning day (Sunday), Beginning hour, Ending month, Ending week, Ending day (Sunday), and Ending hour; "UTC Time Setting" with a text input field containing "2021-08-30 13:23:19"; and "Version" with a text input field containing "1.3.0.0.5b102". There are "Submit" and "Refresh" buttons for each section.

Parameter Configuration-CP Configuration



Enter ChargerPoint ID (if no, default is 1234), Group Number (if no, default is 1234), EVSE ID: 1-1
#1 Gun Address:1, #2 Gun Address:2
Enter QR code for the two charging cables.

The screenshot shows the Star Charge web interface for CP Configuration. The left sidebar contains navigation links: Home, Software Configuration, CP Configuration (highlighted), CP Status, Power Unit Configuration, Power Unit Status, SmartOPS, and Upload And Download. The main content area is titled 'CP Configuration' and includes a breadcrumb trail: Home / Configuration / CP Configuration. The 'Identification' section, highlighted with a red box, contains the following fields:

CP Identity	Group Number	EVSE ID
<input type="text" value="1234"/>	<input type="text" value="1234"/>	<input type="text" value="1-1"/>
#1 Gun Address	#2 Gun Address	
<input type="text" value="1"/>	<input type="text" value="2"/>	
#1 Gun QRcode	#2 Gun QRcode	
<input type="text" value="1234567801"/>	<input type="text" value="1234567802"/>	

Buttons for 'Submit' and 'Refresh' are located to the right of the Identification section. Below this is the 'Compatible Configuration' section, which includes fields for Cardreader Block Number, Cardreader Key, Screen Enable (set to Disable), ID Cover (set to Disable), and QR-Code Enable (set to Disable).

Parameter Configuration-CP Configuration



The default settings are shown as below (Maximum power is set according to the requirements. If you want to change the value of current, voltage and power, administrator account is required, pls contact the local service engineer):

If the gun type of the Titan is **CCS2**, you can configure it with the following default parameter.

The screenshot shows a web-based configuration interface. On the left is a dark sidebar with a "Contents" menu listing: Quick Setup, Software Configuration, CP Configuration (highlighted in orange), CP Status, Power Unit Configuration, Power Unit Status, SmartOPS, and Upload And Download. The main area is titled "Gun" and contains a sub-section "EVSE 1". Under "EVSE 1", there are two tabs: "Conn 1" and "Conn 2" (which is active). The configuration for "Conn 2" is displayed in a grid. The "Gun Type" dropdown is set to "CCS2". The "Meter" dropdown is set to "Type B". The "Insulation Board" dropdown is set to "Enable". The "PLC Board" dropdown is set to "Type A". The "Pre-Precharge" dropdown is set to "Unknow". The numerical fields are: Maximum Voltage(V) = 1000, Minimum Voltage(V) = 150, Maximum Current(A) = 200, Maximum Power(kW) = 180, and Maximum Temperatur(°C) = 90.

Gun Type	Meter
CCS2	Type B
Maximum Voltage(V)	Insulation Board
1000	Enable
Minimum Voltage(V)	PLC Board
150	Type A
Maximum Current(A)	Pre-Precharge
200	Unknow
Maximum Power(kW)	
180	
Maximum Temperatur(°C)	
90	

Parameter Configuration-CP Configuration



The default settings are shown as below (Maximum power is set according to the requirements. If you want to change the value of current, voltage and power, administrator account is required, pls contact the local service engineer):

If the gun type of the Titan is **CHAdEMO**, you can configure it with the following default parameter.

The screenshot shows a web-based configuration interface. On the left is a dark sidebar with a "Contents" menu listing: Quick Setup, Software Configuration, CP Configuration (highlighted in orange), CP Status, Power Unit Configuration, Power Unit Status, SmartOPS, and Upload And Download. The main area is titled "Gun" and contains a sub-section "EVSE 1". Under "EVSE 1", there are two tabs: "Conn 1" (active) and "Conn 2". The "Conn 1" configuration includes several fields: "Gun Type" (dropdown menu set to "CHAdEMO"), "Maximum Voltage(V)" (input field with "500"), "Minimum Voltage(V)" (input field with "150"), "Maximum Current(A)" (input field with "125"), "Maximum Power(kW)" (input field with "62"), and "Maximum Temperatur(°C)" (input field with "90"). To the right of these fields are three more dropdown menus: "Meter" (set to "Type B"), "Insulation Board" (set to "Enable"), and "PLC Board" (set to "Type A"). Below these is a "Pre-Precharge" dropdown menu set to "Unknow".

Parameter Configuration-Power Unit Configuration



The default settings are shown as below (Maximum power is set according to the requirements. If you want to change the value of current, voltage and power, administrator account is required, pls contact the local service engineer):

The screenshot shows the 'Power Unit Configuration' page. The left sidebar contains navigation options: Home, Software Configuration, CP Configuration, CP Status, Power Unit Configuration (highlighted), Power Unit Status, SmartOPS, and Upload And Download. The main content area is titled 'Power Unit Configuration' and includes a breadcrumb 'Home / Configuration / Power Unit Configuration'. Below this is a 'Common' section with several configuration fields:

- 180_relay
- 180_pdu
- 360_pdu
- Module Layout: Hand In Hand (dropdown)
- Gun Amount: 2 (input)
- Power Unit Amount: 1 (input)
- Maximum Power(kW): 180 (input)
- PDU Type: Disable (dropdown)
- PDU Amount: 2 (input)
- PDU Relay Amount: 6 (input)
- Fan Type: Disable (dropdown)

At the bottom of the 'Common' section are 'Submit' and 'Refresh' buttons. Below the 'Common' section is a 'Power Module' section with a table for configuration:

Under-voltage Protection(V)	Module SN	Group Number	Module SN	Group Number
200	1	1		

The screenshot shows the 'Power Module' configuration page. The left sidebar is identical to the previous screenshot. The main content area is titled 'Power Module' and includes a breadcrumb 'Home / Configuration / Power Unit Configuration'. Below this is a 'Power Module' section with several configuration fields:

- Under-voltage Protection(V): 200 (input)
- Over-voltage Protection(V): 260 (input)
- Module Amount: 6 (input)
- Module Type: StarCharge 30KW (dropdown)

Below these fields are two tables for configuration:

Module SN	Group Number	Module SN	Group Number
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		

At the bottom of the 'Power Module' section are 'Submit' and 'Refresh' buttons. Below the 'Power Module' section is a 'Sensor' section with a table for configuration:

Temperature Sensor	Temperature Threshold
--------------------	-----------------------

Power Module Address Configuration

Set the power address as the picture below. Workflow refers to the following slides.



Power Module Address Configuration




Turn off the door sensor(administrator account is required).

The screenshot shows the Star Charge web interface. The left sidebar contains navigation links: Home, Software Configuration, CP Configuration (highlighted), CP Status, Power Unit Configuration, Power Unit Status, SmartOPS, and Upload And Download. The main content area is divided into two sections. The top section, titled "Power Unit Configuration", contains input fields for "Maximum Current(A)" (200), "Maximum Power(kW)" (180), and "Maximum Temperature(°C)" (90). Below these fields are "Submit" and "Refresh" buttons. The bottom section, titled "Sensor", contains four dropdown menus: "Temperature Sensor" (Disable), "Temperature Threshold(°C)", "Water Level Sensor" (Disable), and "Door Sensor" (Disable). The "Door Sensor" dropdown is highlighted with a red box. Below the sensor settings are "Submit" and "Refresh" buttons. The footer shows the URL "www.starcharge.com".

The screenshot shows the Star Charge web interface. The left sidebar contains navigation links: Home, Software Configuration, CP Configuration, CP Status, Power Unit Configuration (highlighted), Power Unit Status, SmartOPS, and Upload And Download. The main content area is divided into two sections. The top section, titled "Protection", contains a "Protection(V)" input field (260) and a "Module Amount" input field (6). Below these are "Submit" and "Refresh" buttons. The middle section, titled "Module Type", shows a dropdown menu set to "StarCharge 30KW" and a grid of 12 input fields arranged in 2 columns and 6 rows, numbered 2 through 7. The bottom section, titled "Sensor", contains four dropdown menus: "Temperature Sensor" (Disable), "Temperature Threshold(°C)", "Water Level Sensor" (Disable), and "Door Sensor" (Disable). The "Door Sensor" dropdown is highlighted with a red box. Below the sensor settings are "Submit" and "Refresh" buttons. The footer shows the URL "www.starcharge.com".

Power Module Address Configuration

Turn on the AC contactor.



The screenshot displays the Star Charge web interface. The top navigation bar includes the Star Charge logo, a language dropdown menu, and a user set dropdown menu. The left sidebar contains a menu with the following items: Home, Software Configuration, CP Configuration, CP Status, Power Unit Configuration, Power Unit Status (highlighted in orange), SmartOPS, and Upload And Download. The main content area is titled "Debug" and contains a table with the following structure:

Type	Parameters	Control
Fan Relay	\	<input type="button" value="Open"/> <input type="button" value="Close"/>
Fan Speed	<input type="text" value="Example : 0-100"/>	<input type="button" value="Submit"/>
AC Relay	\	<input type="button" value="Open"/> <input type="button" value="Close"/>
PDU Relay	<input type="text" value="Pdu Id"/> <input type="text" value="Relay Id"/>	<input type="button" value="Open"/> <input type="button" value="Close"/>
Power Check	<input type="text" value="Gun Id"/> <input type="text" value="Request Voltage(V)"/> <input type="text" value="Request Current(A)"/>	<input type="button" value="Start"/> <input type="button" value="Stop"/>

The "Open" button for the AC Relay is highlighted with a red border. At the bottom of the page, the URL "www.starcharge.com" is visible.

Power Module Address Configuration

1. Press ▲ or ▼, change the interface;
2. Press ▲ or ▼ for about the 2.5s, the value will be flashing;
3. Press ▲ or ▼ to change the value;
4. Press ▼ for about 2.5s to save the value.



Power Module Address Configuration



Turn off the AC contactor.

The screenshot shows the Star Charge web interface. On the left is a navigation menu with items: Home, Software Configuration, CP Configuration, CP Status, Power Unit Configuration, Power Unit Status (highlighted), SmartOPS, and Upload And Download. The top right of the page has 'Language' and 'User Set' dropdowns. The main content area is titled 'Debug' and contains a table with the following data:

Type	Parameters	Control
Fan Relay	\	Open Close
Fan Speed	Example : 0-100	Submit
AC Relay	\	Open Close
PDU Relay	Pdu Id Relay Id	Open Close
Power Check	Gun Id Request Voltage(V) Request Current(A)	Start Stop

At the bottom of the page, the URL 'www.starcharge.com' is visible.

Power Module Address Configuration



Turn on the door sensor (administrator account is required).

The screenshot shows the Star Charge web interface. The left sidebar contains navigation links: Home, Software Configuration, CP Configuration (highlighted), CP Status, Power Unit Configuration, Power Unit Status, SmartOPS, and Upload And Download. The main content area is divided into two sections. The top section, titled "Power Unit Configuration", contains input fields for "Maximum Current(A)" (200), "Maximum Power(kW)" (180), and "Maximum Temperature(°C)" (90). Below these fields are "Submit" and "Refresh" buttons. The bottom section, titled "Sensor", contains four dropdown menus: "Temperature Sensor" (Disable), "Temperature Threshold(°C)", "Water Level Sensor" (Disable), and "Door Sensor" (Enable). The "Door Sensor" dropdown is highlighted with a red box. Below the "Door Sensor" dropdown are "Submit" and "Refresh" buttons, with the "Submit" button also highlighted with a red box. The footer of the page displays "www.starcharge.com".

The screenshot shows the Star Charge web interface. The left sidebar contains navigation links: Home, Software Configuration, CP Configuration, CP Status, Power Unit Configuration (highlighted), Power Unit Status, SmartOPS, and Upload And Download. The main content area is divided into two sections. The top section, titled "Protection", contains a "Protection(V)" input field (260) and a "Module Amount" input field (6). Below these are "Submit" and "Refresh" buttons. The middle section, titled "Module Type", contains a dropdown menu for "Module Type" (StarCharge 30KW) and a table with 6 rows and 2 columns of input fields. The bottom section, titled "Sensor", contains four dropdown menus: "Temperature Sensor" (Disable), "Temperature Threshold(°C)", "Water Level Sensor" (Disable), and "Door Sensor" (Enable). The "Door Sensor" dropdown is highlighted with a red box. Below the "Door Sensor" dropdown are "Submit" and "Refresh" buttons, with the "Submit" button also highlighted with a red box. The footer of the page displays "www.starcharge.com".

Charging Function Check



Charging Test

1. Swipe the RFID card
2. Scan QR Code

Hardware Function Test

1. Limit switch: Open the door of EVSE when charging, the EVSE should stop charging.
2. Emergency stop: Press the emergency stop button on the EVSE when charging, the EVSE should stop charging.
3. Fan: Check whether the fan inside of EVSE and fan of power module during charging.
4. Meter: Check whether the meter measures accurately during charging.
5. Charging cable: There's no burrs, no sharp edges, no ignition or burning, no loosen insulation cap on the easy touch surface of the charging cable. It's neither too tight nor too loose when inserting and pulling out the charging cable.

Commissioning Report



星星充电
Star Charge

Commissioning Report



After the commissioning work for the EVSE, the engineer should give a basic training relating to the main characteristics of the EVSE to guide the customer on using and some basic knowledge. The training form can be through either document or practical explanation on-site. The training content should cover safety knowledge, basic charging procedure and etc.

After confirming customer's satisfaction, get the training file signed and recorded properly. Refer to Appendix 1 "Customer training record sheet" for details.

Fill in the "Commissioning Report" after all the items have passed.

Mobile Power Grid Ecosystem

Future has Come



WeChat



APP

Star Charge, Faster and Smarter!
No.39 Longhui Road, Wujin, Changzhou, Jiangsu, China
Hot Line: 400 8280 768
WWW.STARCHARGE.COM