

Sep 4th, 2024

How to use SD card update Saturn screen

European service team


Ruo Yi, technical support engineer



How to use SD card update Saturn screen


1. Prepare the SD card.

Get a SD card (8 or 16GB size), format SD card first and then copy the contents of screen firmware to SD. If you don't have SD card, you can take the SD card from charger control board.



How to use SD card update Saturn screen

2. Turn off power supply to charger, open front cover. Insert the prepared SD card into slot in the front cover.




SD card slot of
screen




How to use SD card update Saturn screen

3. Turn on the power supply to the charger. When the screen get power, the update process will automatically begin.



The left circuit breaker control the power to screen.





How to use SD card update Saturn screen

4. The update process will take 1 minute. When the process finished, turn off the power to power supply and take out the SD card from slot. The update process is finished.

If the SD card is originally from the control board, please format it before putting it back to control board.





Thank You.

Connect the World. Connect the People.



Headquarter: No. 39 Longhui Road, Wujin High-tech Zone, Changzhou, Jiangsu, China
China Office: Building 5, Innovation and Research Port, Changzhou, Jiangsu, China
Europe Office: Rugbyring 12, 65428 Rüsselsheim, Germany
APAC Office: 2 Kung Chong Road, #05-01 AA Centre, Singapore 159140
America Office: 46571 Fremont Blvd, Fremont, CA 94538

www.starcharge.com